

Laboratory Services

Lebanon, New Hampshire Plattsburgh, New York Williston, Vermont Ph 802-879-4333 www.endynelabs.com

Dear Client,

The sample containers included in this package are sufficient to perform the testing required in **Appendix A, Tables A11-5 and A11-7** of the Vermont Water Supply Rule.

The Coliform test needs to be analyzed within 24 hours of collection. You must sample the same day of delivery or late in the evening the day before delivery to the laboratory.

Follow the sampling instructions below to obtain valid results. Samples should be collected before water treatment systems, such as softeners or UV light systems.

Odor 1-16ozAmber Glass

Arsenic, Iron, Manganese, Sodium, Uranium
1-16oz Plastic
Chloride, Nitrate, Nitrite, pH
1-8oz Plastic

Do not remove the aerator. Run the water for 5 minutes. Reduce the flow to minimize splashing. Fill the bottles to the neck and cap tightly.

Total Coliform/ E. coli

150ml Bacteria Bottle

Fill between the 100ml and 120ml lines on the bottle. Refer to the separate Total Coliform instructions for specific guidance.

Also included in this shipment is a form entitled "Chain-of-Custody Record". This is a formal record used to document the custody of the sample. Complete all of the information at the top of the form

If mailing the samples, please sign the "relinquished by:" and "Date/Time" lines at the bottom of the form. If delivering the samples in person, you may sign this form at the Laboratory.

Samples must be kept refrigerated or packed in ice from the time of sampling until receipt at the Laboratory. Several options are available if the samples are to be mailed. Please contact the Laboratory for suggestions.



Effective: July 9, 2019