

## **Laboratory Services**

160 James Brown Drive Williston, Vermont 05495 Ph 802-879-4333 www.endynelabs.com

## New Requirement for Total and Dissolved Phosphorus COD and TOC Sampling

Please leave a small amount of air in your vials for TP, TDP, COD and TOC so they can be homogenized easily before analysis.

Fill to the bend in the neck of vial. Thank You!

