



ENDYNE, INC.

Laboratory Services

Lebanon, New Hampshire
Plattsburgh, New York
Williston, Vermont
www.endynelabs.com

LEAD AND COPPER

SAMPLING INSTRUCTIONS

CHLORINATED AND NON-CHLORINATED

WATER SYSTEMS

FOR COMPLIANCE TESTING (WSID)

EPA 200.7/200.8

1--1 Liter Plastic

Hold Time: 6 Months

- Sample should be collected from the first draw of water at the point of consumption.-
The sample should be taken from a faucet or tap that sees regular use.
- Allow water to sit in the pipes for at least six hours or preferably overnight prior to taking the sample. Do not perform any special flushing prior to letting water sit in the pipes.
- Do Not remove Aerator/screen
- Collect the sample before using any water in the home. The first drop of water from the tap should go into the sample container.
- Fill container exactly to the 1000ml line as marked on the side of the bottle.
- Fill the bottle as though you are filling a drinking glass. Open the faucet as far as possible for maximum flow.
- Sample preservation is done with **Nitric Acid** performed at the Laboratory.

Sample does not require Refrigeration

Samples collected must be received at the laboratory and preserved with Nitric Acid within 14 days

